

# DDRUM BT-9 Upgrade Guide

Development Dept.


V1.0

# Prepare upgrade

- BT9 machine
  - BT9 power cable
  - USB data cable
- PC upgrade app
  - BT9\_Upgrader upgrade program.  
**binary/BT9\_Upgrader.exe**



- Upgrade firmware file
  - In the TDX-Drum\_Upgrader program folder.  
**binary/xxx.hex**



# Firmware upgrade

- Connect the BT9 module to your PC with a USB data cable.
- Press and hold the DOWN button and press the POWER button to enter USB Upgrade mode
- Run the DDRUM\_BT-9\_UPGRADER.exe file and proceed with the update in the following order.

